

BEYOND THE BURN: WHY THE MOST HEAVILY DAMAGED AREA ISN'T ALWAYS THE FIRE'S ORIGIN

McKayla Major BSc., C.F.E.I., IAAI-FIT

One of the fundamental objectives of a fire investigation is to distinguish between damage resulting from fire exposure and evidence associated with the fire's ignition. Items located within or near the area of origin may sustain significant thermal damage simply because of their proximity to the developing fire. For example, a heavily damaged appliance may attract attention during an investigation; however, the extent of damage alone does not establish that the appliance was responsible for ignition.


DAMAGE DOES NOT EQUAL CAUSATION

Fire damage is influenced by numerous factors, including the duration and intensity of fire exposure, ventilation, nearby combustible materials, the construction of the appliance, and the direction in which the fire developed.

For example, an electrical appliance located within the area of origin may be extensively damaged even though it was not operating when the fire began. Conversely, a relatively small electrical component responsible for ignition may sustain less obvious damage or may be partially destroyed as the fire progresses. For this reason, an origin and cause investigation should not begin with the assumption that the most visibly damaged appliance was responsible. Instead, the physical evidence must be considered within the context of the entire fire scene.



Fire investigation involves developing and evaluating potential hypotheses against the available evidence. Witness statements, scene examination, electrical and appliance examinations, fire patterns, surveillance footage and laboratory findings may all contribute to the analysis. A potential ignition source should be supported by the evidence rather than selected simply because it sustained the greatest amount of damage.



DETERMING AREA OF ORIGIN

Before evaluating whether a particular appliance caused the fire, investigators work to determine where the fire originated. This involves examining fire patterns and damage throughout the structure and considering how heat, smoke, and flames moved from the developing fire. Investigators may examine areas of varying damage, patterns on walls and structural components, ventilation effects, and the location of potential fuel packages and ignition sources. Once an area of origin has been identified, the appliances, electrical systems, heating equipment, open-flame sources, and other potential ignition sources within that area can be evaluated.

THE INFLUENCE OF VENTILATION ON FIRE DAMAGE

Ventilation plays a significant role in fire development and spread. Open doors, windows, ventilation ducts, and other openings can influence the movement of air, smoke, and hot gases throughout a structure. As a fire develops, the availability of oxygen can affect its intensity and growth. Areas with increased airflow may experience more extensive burning than other portions of the structure, even when located away from the initial ignition point. For example, a fire originating in one section of a room may spread toward a ventilation opening, where the availability of oxygen contributes to increased burning. The resulting damage near that opening may be more severe than the damage surrounding the actual area of origin. Similarly, ventilation ducts and concealed spaces may provide pathways for the movement of hot gases and flames, allowing fire damage to develop in areas removed from the initial fire location.

A ventilation system can influence the distribution of fire damage in several ways:

- **Movement of hot gases:** Ductwork and associated openings may provide pathways for heated gases to travel away from the initial fire location.
- **Airflow and oxygen availability:** Where ventilation introduces additional air into a fire-affected compartment, it may support increased combustion and localized fire growth.
- **Heat transfer:** Metal ductwork can transfer heat to adjacent materials through conduction and radiation, although the extent of heating depends on the temperature, duration of exposure, duct construction, and surrounding conditions.
- **Concealed fire:** Duct penetrations and inadequately protected openings within walls, floors, and ceiling assemblies may permit fire and hot gases to spread into concealed spaces.
- **Prolonged exposure:** Combustible materials surrounding ventilation equipment may experience sustained heating, resulting in extensive charring or material consumption.



Figure 1 – Illustrative Fire Scene

AI-generated illustration depicting a fire-damaged mechanical room where the area surrounding the HVAC system exhibits extensive damage due to fire spread and ventilation effects. The hypothetical area of origin is identified near an electrical receptacle, demonstrating how the most heavily damaged area may not necessarily represent the location of initial ignition.


HOW DIFFERENT MATERIALS INFLUENCE FIRE DAMAGE

The type, quantity, and arrangement of combustible materials within a structure can significantly influence the development and severity of a fire. Different materials exhibit varying ignition characteristics, burning rates, heat release rates, and responses to thermal exposure. For example, upholstered furniture containing polyurethane foam can contribute to rapid fire growth and significant heat release once ignited. In comparison, solid wood materials may undergo surface charring, with the resulting char layer influencing the rate at which heat penetrates the remaining material.

Synthetic materials, plastics, textiles, and wood-based products can also produce different fire effects, including melting, deformation, charring, and varying degrees of material consumption. Consequently, an area containing a greater concentration of combustible materials may sustain more extensive damage than the initial area of ignition.

Metal components, such as HVAC units, ventilation ducts, and electrical enclosures, respond differently to fire exposure than combustible materials. Although steel and other metals commonly used in HVAC systems do not typically contribute fuel to a fire, they can absorb, conduct, and transfer heat to surrounding materials. During prolonged fire exposure, metal components may exhibit discolouration, oxidation, warping, and deformation. HVAC units may also contain combustible components, including plastic housings, wiring insulation, filters, and other internal materials that can ignite or sustain additional damage. As a result, an HVAC unit located within an area of significant fire exposure may exhibit extensive damage even when the fire originated elsewhere.

The presence of severe thermal damage to metal equipment does not independently establish that the equipment was responsible for ignition. Investigators must consider whether the observed damage resulted from an internal equipment failure or exposure to an external fire.



DURATION OF EXPOSURE VS. TEMPERATURE

The severity of fire damage is influenced not only by the temperature reached during a fire but also by the length of time materials are exposed to elevated temperatures.

A material subjected to prolonged heating may exhibit extensive charring or deformation, while another material exposed to higher temperatures for a shorter period may sustain less damage. For this reason, the greatest degree of damage does not necessarily indicate the location of the highest temperature or the initial ignition point.

The extent of damage is also influenced by the following:

- Material's physical properties
- The rate of heat transfer
- The availability of oxygen and combustible fuel




Figure 2 – AI-generated Illustrative Fire Scene

THE IMPACT OF FLASHOVER ON FIRE PATTERNS

Flashover is a significant stage of fire development that can complicate the interpretation of fire patterns and the determination of a fire's origin. Flashover occurs when the thermal conditions within a compartment cause exposed combustible materials to become involved in combustion over a relatively short period. As a fire develops, heat accumulates within the compartment, and radiant heat from the upper hot gas layer contributes to the heating of surrounding combustible surfaces. When flashover occurs, the fire transitions from localized burning to widespread involvement of combustible materials throughout the compartment. Following flashover, extensive burning may occur across multiple areas of the room, resulting in widespread charring, material consumption, and structural damage. These conditions can alter or destroy fire patterns that developed during the earlier stages of the fire. As a result, areas that were not initially involved in the fire may exhibit damage comparable to, or greater than, the original area of ignition.



POST-FLASHOVER

In a post-flashover fire, the distribution and severity of damage may be influenced by ventilation, fuel availability, and the duration of burning rather than solely by proximity to the initial ignition point.

For example, an area near a window, doorway, or ventilation opening may experience increased burning due to the availability of oxygen, resulting in more extensive damage than the area where the fire began. This can make it challenging to distinguish between damage associated with the initial fire development and damage produced during subsequent full-room involvement.

KEY INVESTIGATIVE CONSIDERATIONS

- **Evaluate fire patterns collectively:** Examine the distribution of charring, material consumption, and structural damage throughout the compartment rather than relying on the most heavily damaged area alone.
- **Consider ventilation effects:** Identify windows, doors, HVAC systems, and other openings that may have influenced airflow, fire intensity, and the resulting fire patterns.
- **Examine protected areas:** Areas shielded from direct flame impingement or radiant heat may preserve evidence of earlier fire development that was destroyed elsewhere.
- **Assess fuel distribution:** Consider the type, quantity, and arrangement of combustible materials that may have contributed to increased burning in particular areas.
- **Examine potential ignition sources:** Evaluate electrical equipment, appliances, heating systems, and other potential ignition sources within areas supported by the fire pattern analysis.
- **Identify fire spread pathways:** Examine wall cavities, ceiling assemblies, ventilation ducts, and structural openings to determine how the fire may have travelled throughout the building.
- **Review witness information and available records:** Statements, surveillance footage, fire alarm data, and observations from responding firefighters may provide valuable information about the fire's early development.
- **Develop and test origin hypotheses:** Evaluate potential areas of origin against the physical evidence, fire dynamics, and available information, considering alternative explanations for the observed damage.